

[4] Host WakeEase Dashboard using GitHub

Step 1: Create a GitHub Repository


- 1. Log in to your GitHub account.
- 2. Navigate to github.com/dashboard.
- 3. Click the *New* button on your GitHub homepage.
- 4. Name your repository and set it to **Public**.
- 5. You can optionally add a README file.
- 6. Click the *Create repository* button.






Step 2: Add index.html file


- 1. Click on the Add file button, then click on the Create new file button.
- 2. Name the file **index.html**; you can paste the content by copying the code from <u>here</u>.
- 3. Click on the *Commit changes...* button.







Step 3: Enable GitHub Pages

- 1. Navigate to the repository's **Settings** tab.
- 2. Scroll down to the **Pages** section.
- 3. Under the **Branch** section:
 - Select branch: Choose main (or any other branch you want).
 - Select folder:
 - Use / (root) if your files are directly in the root directory.
 - Use /docs if you want to organise your files in a docs/ folder.
 - Click the Save button.



- 4. Navigate back to the repository's **Code** tab.
- 5. Look at bottom right, and you will see **Deployments**.
- 6. Click on the **github-pages**.
- 7. Your will be redirected to **Deployments** view.
- 8. Click on the website URL, and you will be able to view your website.





Step 4: Export JSON format from MongoDB in Google Cloud VM

- 1. Open Google Cloud Console and launch SSH-in-browser from VM instance
- 2. Run the following mongoexport commands to export each collection from your WakeEase database into a JSON file:
 - mongoexport --db WakeEase --collection fan_duration --out <file-directory>/fan duration.json
 - mongoexport --db WakeEase --collection led_duration --out <file-directory>/led duration.json
 - mongoexport --db WakeEase --collection sleep_duration --out <file-directory>/sleep_duration.json
 - mongoexport --db WakeEase --collection response_time --out <file-directory>/response_time.json

Note: You may check your file directory by executing pwd at the terminal. Make sure that WakeEase database exists together with the collections.

```
### SSH-in-browser

### PDOWNLOAD FILE DOWNLOAD FILE DOWNL
```

- 3. Create a Python script to format the JSON file.
 - sudo nano formatting_json.py
 - Replace the file content with:

```
import json
# Define file paths for all collections
collections = [
    "<file-directory>/fan duration.json",
    "<file-directory>/led duration.json",
    "<file-directory>/sleep duration.json",
    "<file-directory>/response time.json"
for file path in collections:
   try:
        # Read the JSON lines file (line-delimited JSON)
        with open(file path, "r") as infile:
            data = [json.loads(line) for line in infile] #
Convert each line to a JSON object
        # Write the formatted JSON as an array back to the same
file
        with open(file path, "w") as outfile:
            json.dump(data, outfile, indent=4) # Add
indentation for readability
        print(f"Formatted JSON saved back to {file path}")
    except Exception as e:
        print(f"Error processing {file path}: {e}")
```

- 4. Save and close the file:
 - CTRL + O, then ENTER to save.
 - CTRL + X to exit.
- 5. Check if the file is updated:
 - sudo nano formatting json.py

- 6. Check all json files, and formatting json.py is available.
 - ls
- 7. Run the Python script to format the JSON files:
 - python3 formatting json.py

```
# UPLOAD FILE DOWNLOAD FILE DO
```


- 8. Check one of the JSON files to see if the file has been formatted correctly.
 - sudo nano fan_duration.json

- This shows that the file is in JSON format.
- CTRL + X to exit.


Step 5: Download JSON Files from GCP to Local Machine

- 1. Click the **DOWNLOAD FILE** button.
- 2. Paste the path for all four JSON files.
- 3. Click *Download* and wait for a while. You may be prompted to retry authentication SSH when you tried to download; just follow the prompt and retry again.

4. You can click on the **Download** icon to view files that have been downloaded.




5. Click on the file to locate the file directory in your local machine.




Step 6: Transfer JSON files to GitHub Repository

- 1. Open the GitHub repository, then add all JSON files into the development branch.
- 2. Click on the *Commit changes* button.



3. Wait for the commit to pass all checks.



4. Access your repository website, and you will be able to view charts that display data sourced from the JSON files.

